

HOT AT ALL TIMES
HOT AT ALL TIMES
POWER DISTRIBUTION BOX
FUSE 12 30A
FUSE 4 15A
HOT IN RUN OR START
HOT IN RUN
INTERIOR FUSE PANEL
FUSE 11 7.5A
FUSE 27 10A
DK BLU/ ORG
BLK/ YEL
RED/ YEL
PPL/ ORG
S237
S213
S207
HEADLAMPS/ FOG LAMPS CIRCUIT (FOG LAMP RELAY)
LT GRN/ YEL
C216
HEADLAMP SWITCH
OFF
PARK
HEAD
RED/YEL
S266
HEADLAMPS CIRCUIT (W/ AUTOLAMPS)
C210
MULTI-FUNCTION SWITCH
FLASH-TO-PASS SWITCH
DIMMER SWITCH
HI
LO
PASS
GRY/ ORG
RED/ BLK
INTERIOR FUSE PANEL
FUSE 33 15A
FUSE 4 10A
FUSE 8 10A
LT GRN/BLK
WHT/ LT GRN
DK BLU/ LT GRN
W/O LAMP OUT WARNING
W/ LAMP OUT WARNING
INSTRUMENT CLUSTER
GRY/ WHT
RED/ YEL
C287
C288
HI BEAM INDICATOR
BRAKE INDICATOR
BLK
S229
G104
PPL/ WHT
S176
DAYTIME RUNNING LAMPS (DRL) MODULE
932 GRY/WHT 1
HI BEAM IND FEED
298 PPL/ORG 3
IGN FEED
162 LT GRN/RED 4
DRL DISABLE
977 PPL/WHT 5
1056 DK BLU/LT GRN 6
HEADLAMPS BATTERY
54 LT GRN/YEL 7
12 LT GRN/BLK 8
HEADLAMPS
LT GRN/ RED
PARKING BRAKE SWITCH
S111
1055 WHT/LT GRN 1
160 DK BLU/WHT 11
1056 DK BLU/LT GRN 12
161 DK GRN/ORG 13
LAMP OUT WARNING MODULE
DK BLU/ WHT
DK GRN/ORG
S112
LT GRN/ BLK
HI
LO
LEFT HEADLAMP
RIGHT HEADLAMP
BLK
S155
G104
S103
G105
DK BLU/ LT GRN
HEADLAMPS/ FOG LAMPS CIRCUIT (FOG LAMP RELAY)
PPL/ WHT
TAN/ LT GRN
BRAKE FLUID LEVEL WARNING SWITCH
LOW
NORMAL
S153
IGNITION SWITCH
P2
P1
START
RUN
OFF
ACC
LOCK
102131